



BT-5000 Battery Powered Tracker Installation Guide

Where to Mount the SolarTrak Box

Ensure that the tracker is installed on a stable surface, and has a **clear view of the sky overhead**.

Installing the Tracker

Tracker should be attached to your equipment with the **provided hardware** to ensure a secure mounting.

1. Install the tracker on a flat surface - **mounting plate face down**.
2. Use 3/4" screws for thinner surfaces and angle bracket installation; use the 2" screws for thicker surfaces.



After Installation

A. Tell your company's SolarTrak Administrator which SolarTrak unit (using the unit's serial number) has been installed on which piece of equipment. Tell your administrator the Manufacturer, and Model number of the equipment, plus any company identifier (like your inventory number).

B. Once installation is completed, the equipment will appear in SolarTrak online in the "Trackers" view as "Unassigned".

C. Once your company's SolarTrak Administrator assigns a specific SolarTrak unit to a specific piece of equipment, the equipment will appear online in the Map View and List View and can be tracked.

UNDER NO CIRCUMSTANCE DO THIS:


-  **Do not** install on moving parts.
-  **Do not** install on sides of vehicles without constant access to the sky. These locations will prevent the GPS from working correctly.

If you have any questions, feel free to call SolarTrak Support at:

1-484-223-4994



BT-5000 WITH MOUNTING PLATE ONLY



BT-5000 WITH MOUNTING PLATE AND BRACKET

SolarTrak was designed by



7620 Cetronia Road, Allentown, PA 18106